Wiring the Cobalt iP Analog

Red and black input to the Cobalts may be reversed depending on the orientation of the motor

Note: Centre connector is not used

+

9-12V Regulated Power Supply

DCD-SY3

DCP-CB1iP

DCD-ASR

+

Wrong direction for switch? Swop the red and black wires on the AlphaSwitch or Cobalt – or swap the pair of inputs to the AlphaSwitch

DCCconcepts Ltd, Unit E, The Sidings, Settle, BD24 9RP, United Kingdom *www.dccconcepts.com * +44 (0) 1729 821 080 * salesuk@dccconcepts.com

20190316