



**The MOST important rule of all is very simple...
BOTH brushes of the motor MUST be isolated from BOTH rails.**