



Cobalt iP Digital and 3-way

Tip 1: Difficult to avoid as shown here on a OO/HO 3-way but orientation of the Cobalt will affect the wiring.

If the point frog shorts, swap the **DCC IN** wires over.

Tip 2: When wiring a 'cascade' of frogs i.e. a ladder of points, check the correct frog polarity on Frog #1 before wiring Frog #2 etc.

If you don't and a frog is wired incorrectly, it will be difficult to identify!

