



Cobalt SS Point Motor Frog Wiring For A Double Slip

The Track To Frog Switch wiring depends on the position of the motor at the slip.

If a frog polarity is incorrect, swap the **FROG L** and **FROG R** wires for that motor.

