



**Alpha Power & Box & NCE
PowerCab & PCP Faceplate Option 1**

WARNING
Do not place any power supply in to
the faceplate input DC power socket

