




NCE PowerCab With Alpha Box, Alpha Power & Alpha Central


Cobalt Digital Point Motor DCP-CB1DIP




Cobalt SS Surface Mount Point Motor DCP-CBSS-2




Solenoid Accessory Decoder DCD-ADS-4SX




NCE PowerCab NCE-Pcab



Set switch to RJ12




Alpha Box DCD-AUX



Red/Black DC Power Lead in the Alpha Power Box




DCD-ACL curly cord or NCE Flat Cord - NOT THE NCE curly cord.






Mains Power



Alpha Central DCD-AEC



Alpha Power DCD-PWR



White link cable supplied in the Alpha Central box.